



PRODUCT INFORMATION

SAFETY FOOTWEAR CARE GUIDELINES

How to Take Care of Safety Shoes

- Avoid abrasive the upper leather or thread on sharp edges that may cause tear or cut on the sole.
- Regularly clean the safety shoes.
- Remove excess mud and contaminants encrusted into the sole to maintain shoe gripping component.
- Clean the shoe with damp cloth and keep it dry thoroughly without force dried by hair dryer or direct under sunlight.
- Recommend to use quality grease on leather footwear instead of solvent.
- Avoid any unauthorised footwear reformation such as mechanical stretching.

It's Time to Replace Your Safety Footwear

1. Wear and Tear

When your safety footwear see through steel toe shine, exposed toecaps, cracked in leather or heel plate rubbed bare.

2. Functionality

When the safety footwear unable to protect you from slipping, falling or foot injury in any condition.

3. Damage

When your safety footwear steel dents inwards caused by puncture.

4. Mileage

Standard mileage usage is around 1500 km mark which equivalent to about one year of daily wear.

SAFETYWARE SDN BHD (432971-X)

Plot 237, Lengkok Perindustrian Bukit Minyak 3, Bukit Minyak Industrial Estate,

14100 Simpang Ampat, Penang, Malaysia.

Tel: +604-5023 882 (8 lines) Fax: +604-5070 882

Email : info@safetyware.com



Malaysia



Singapore



United Kingdom