SafetyFirst

Instructions For Use



Spring back safety guards for safe top cuts




3 Button design for convenient tray cuts



Blade-less tape splitting eliminates cut injuries

EZ4™ Guarded Spring-Back Safety Cutter AMBIDEXTROUS - For Right & Left Handed Users

Blade Change



Push quick change lever and open safety cutter.



Remove used blade from blade retainer and dispose of safely.



Remove spare blade from blade compartment. Use only S Series replacement blades: #SP-017, SPD-017 or PBDSP017B





Insert new blade underneath blade retainer, align blade notch with alignment tab. Close cutter.



For Information Call: (800) 229-2233 Email: info@phcsafety.com www.phcsafety.com



