




SR 500 EX

SYSTEM OVERVIEW

For more information:
Email : Info@safetyware.com
www.safetyware.com



| No. | Description | Name | Art No. | ATEX code |
|-----|---------------------------------|------------|----------|---------------|
| 1. | Fan unit | SR 500 EX | R06-2001 | |
| 2. | Combined filter A1BE2K1-Hg-P3 R | SR 599 | H02-7312 | |
| 3. | Gas filter A1BE2K1 | SR 597 | H02-7212 | |
| 4. | Gas filter ABE1 | SR 515 | H02-7112 | |
| 5. | Gas filter A2 | SR 518 | H02-7012 | |
| 6. | Filter adapter | SR 511 | R06-0105 | |
| 7. | Particle filter P3 R | SR 510 | H02-1312 | |
| 8. | Pre-filter | SR 221 | H02-0312 | |
| 9. | Pre-filter holder | SR 512 EX | R06-2023 | |
| 10. | Particle filter P3 R | SR 710 | H02-1512 | |
| 11. | Pre-filter holder | SR 5153 | R01-0604 | |
| 12. | Steel net disc | SR 336 | T01-2001 | |
| 13. | Battery | SR 501 EX | R06-2002 | |
| 14. | Battery charger | SR 513 EX | R06-2003 | |
| 15. | Hood | SR 520 S/M | H06-0312 | ^{A)} |
| | Hood | SR 520 M/L | H06-0212 | ^{B)} |
| 16. | Hood | SR 530 | H06-0412 | ^{B)} |
| 17. | Hood | SR 562 | H06-5112 | ^{B)} |
| 18. | Hood | SR 561 | H06-5012 | ^{B)} |
| 19. | Face shield | SR 540 EX | H06-6012 | ^{A)} |
| 20. | Alt. Visor | SR 545 | T06-0502 | |
| 21. | Helmet with visor | SR 580 | H06-8012 | ^{A)} |

| No. | Description | Name | Art No. | ATEX code |
|-----|---------------------------------------|-----------|----------|---------------|
| 22. | Full face mask laminated glass visor | SR 200 | H01-1312 | ^{A)} |
| | Full face mask PC-visor | SR 200 | H01-1212 | ^{A)} |
| 23. | Breathing hose PU | SR 550 | T01-1216 | |
| | Breathing hose rubber | SR 551 | T01-1218 | |
| 24. | Spectacle frame for corrective lenses | SR 341 | T01-1201 | |
| 25. | Head harness rubber | SR 340 | T01-1215 | |
| 26. | Name label | SR 368 | R09-0101 | |
| 27. | Protective hood | SR 64 | H09-0301 | |
| 28. | Chemical hood | SR 345 | H09-1012 | |
| 29. | Harness EX | SR 552 EX | T06-2002 | |
| 30. | Belt cotton EX | SR 508 EX | R06-2148 | |
| 31. | Belt leather EX | SR 504 EX | T06-2149 | |
| 32. | Belt rubber EX | SR 503 EX | T06-2150 | |

^{A)} II 2 G Ex Ib IIA T3 Gb / II 2 D Ex Ib IIIC T195°C Db
^{B)} II 2 G Ex Ib IIB T3 Gb / II 2 D Ex Ib IIIC T195°C Db

