



Ambidextrous 3-Button Cutting gives flexibility of use


Ergonomic, lightweight, high visibility color



Retractable safety hood conceals blade



Safety Point Blade non-removable stainless steel safety blade




One-time release automatically prevents slip-off cuts. Push once to cut and cutter resets it's hood automatically.



Blade-less Tape Splitting eliminates cut injuries.

We've Got You Covered.

RSC-432 Disposable Safety Cutter



Push Release Button forward allowing guard to retract and expose the blade

After the cut the blade guard hood relocks automatically, preventing slip off cuts, with or without button pressure.



Certified food safe by NSF® as a food service tool.



Right and left side push buttons are ideally positioned for efficiently cutting open boxes

- Automatic re-locking safety hood snaps back, with or without button pressure
- 3 button design
- High visibility color
- Non-removable stainless steel safety point blade
- Ergonomically- designed handle maximizes comfort
- Cut boxes, packaging tape, clamshell packaging
- Safely used in restaurants* / retail stores

* Sanitize cutter before each use.

For more information, please contact

Safetyware Sdn. Bhd. (632971-X)
info@safetyware.com
www.safetyware.com

Penang : +604-5023 882 (8 Lines)
Melaka : +606-3363 882 (2 Lines)
Johor : +607-3576 882 (3 Lines)
Kuala Lumpur : +603-6262 0882 (4 Lines)
Singapore : +65 6744 0882



Working Safe Everyday.™