

# ESE6000SS Decked Mounted Eye Washer

## A) Installation

1. The water supply line should be at least 1/2" OD and should be copper or other corrosion resistant material.
2. Decked mounted require a 1-3/8" diameter mounting hole.
3. Thoroughly clean and flush the supply line before install the product.
4. Product have a 3/8" NPT male thread on the water inlet. Use PTFE tape or other pipe sealant to seal this thread. DO NOT USE SEALANT.
5. The product are fully assembled and factory tested before packing.

## B) Operation

1. In the event of a chemical splash or spill, the affected area of the victim's body must be flushed immediately for at least 15 minutes.
2. For chemical spills to the eyes, the user should hold his or her eyes open as wide as possible to permit the water to reach all areas around the eyes.
3. Rinsing the affected area for 15 minutes is only the first step in treating exposure to a hazardous chemical. Please see a doctor or other trained medical specialist as soon as possible.

## 3) Maintenance

1. Clean the product using a soft cloth and soapy water.  
NEVER USE ANY CLEANING AGENT WITH AMMONIA.
2. Weekly activated the product to assure proper operation. Make sure the equipment is in good operation condition.