

Perfect fit means great protection



1 Check the mask. Sling the neck strap over your head before fitting it to your face.

2 Start with the chin, then cup the mask over your mouth and nose.

3 Pull the head strap over your head and position it on the crest of your head. Never fit the harness over a cap or a hard hat.

Tighten the head harness at the buckle until the mask is tight but comfortable against your face.



4 Pull the bottom straps outwards a few times to even out the tension and to make sure the top head strap is tight and secure.

Negative user seal check

Place the palm of your hand lightly over the hole on the pre-filter holder to make it tight.

Do not push so hard that the respirator's shape is affected.

Take a deep breath and hold your breath for about 10 s. If the mask is tight, it will be pressed against your face.



NOTE! If any leakage is detected, check the inhalation and exhalation valves, adjust the straps of head harness or switch to alternative size of the respirator. Repeat the fit check until there is no leakage.